

# ASSEMBLY manual

The Quick Start Guide is not a substitute for the product documentation. For your own safety, read the complete product documentation before assembling the Bed Frame and putting it into operation.

**01** **A B C TOOL**

DO NOT REMOVE STRAPPING TAPE

LOOK AT LABELS ON FRAME ELEMENTS

ENSURE HOLES ARE ALIGNED

4x

**02** **D ASSEMBLY SUPPORT**

LIFT FRAME ONTO ASSEMBLY SUPPORTS

**03** **E F**

PRESS COVERS FIRMLY INTO PLACE

4x

**04** **L P**

TURN SCREWS UNTIL HAND-TIGHT

REMOVE STRAPPING TAPE BEFORE MOUNTING THE PLATFORMS

**05** **M**

LAY BASE PLATFORM FACE DOWN

**06** **H I J K G**

ENSURE ALL PLUGS ARE ORIENTED CORRECTLY

BE CAREFUL NOT TO TRIP OVER CABLES

DO NOT CONNECT THE SYSTEM TO THE MAINS BEFORE FINISHING ASSEMBLY

2x

**SILVERstandard**

12 PIN, 10 PIN, 8 PIN

**SILVERstandard+ (with Massage Function)**

2 PIN, 12 PIN, 10 PIN, 8 PIN

**07** **N O P**

TURN SCREWS UNTIL HAND-TIGHT

**08** **H M**

MOUNT USB MODULES ONTO BASE PLATFORM

2x

**09**

**Before using your SILVERstandard for first time, please:**

- Place the mattress on the Bed Frame
- Plug the Power Converter into the mains
- Pair your Remote Control with the Bed Frame
- Relax!

**ONLY FOR SILVERstandard+**

DO YOU NEED support?




Watch the assembly video at [adjustables.logicdata.net](https://adjustables.logicdata.net)

Technical problems? Contact LOGICDATA support:  
Phone Number: 800.305.1925 | Email: [support.us@logicdata.net](mailto:support.us@logicdata.net)

Always provide the product name and revision status when requesting support.



adjustables.logicdata.net




The SILVER Series by



# SILVERstandard





## REMOTE control



FOR FURTHER DETAILS read the owner's manual.

silverseries.logicdata.net

## COMPONENTS overview



LOGICDATA  
MOTION FOR YOUR LIFE

**P** 14x MOUNTING SCREW (PLATFORMS)

\* only with SILVERstandard+

QUICK START GUIDE

OWNER'S MANUAL

